







































































Original	Replacement	Original	Replacement
 RCVR On	 Power	 RCVR Test / Menu	 Menu
 RCVR Standby	 Shift + Power	 RCVR Audio	 Dual
 RCVR Sleep	 Sleep	 RCVR Level	 Media
 RCVR Return	 Back	 RCVR Level Up	 Smart
 RCVR Setup	 Options	 RCVR I<<	 I<<
 RCVR Disc+	 Ch +	 RCVR Play	 Play
 RCVR Disc-	 Ch -	 RCVR >>I	 >>I
 RCVR Up	 Up	 RCVR <<	 <<
 RCVR Left	 Left	 RCVR Stop	 Stop
 RCVR Enter	 Ok	 RCVR >>	 >>
 RCVR Right	 Right	 RCVR Rec /	 Rec
 RCVR Down	 Down	 RCVR Pause / Play Rev.	 Pause
 RCVR Vol+	 Vol +	 Open / Close	 Eject
 RCVR Vol-	 Vol -	 RCVR Input Sel.	 1
 RCVR Muting	 Mute	 RCVR Input Sel.	 2
 RCVR CH Sel / Top Menu	 Shift + Menu	 RCVR Input Sel.	 3
 RCVR CH Sel / Top Menu	 D. Menu	 RCVR Input Sel.	 4










































































Original	Replacement	Original	Replacement
T1 RCVR Input Sel.	5 5		
T2 RCVR Input Sel.	6 6		
V3 RCVR Input Sel.	7 7		
V4 RCVR Input Sel.	8 8		
TUN RCVR Input Sel.	9 9		
PH RCVR Input Sel.	0 0		
1 STEREO RCVR Stereo	SHIFT + 1 Shift + 1		
2 DIRECT RCVR Direct	SHIFT + 2 Shift + 2		
3 DSP RCVR DSP	SHIFT + 3 Shift + 3		
4 SURR RCVR SURR	SHIFT + 4 Shift + 4		
5 A.ST RCVR A.ST	SHIFT + 5 Shift + 5		
6 DSP RCVR DSP	SHIFT + 6 Shift + 6		
7 SP A RCVR SP A	SHIFT + 7 Shift + 7		
8 SP B RCVR SP B	SHIFT + 8 Shift + 8		
9 Re-EQ RCVR Re-EQ	SHIFT + 9 Shift + 9		
0 DIMMER RCVR Dimmer	SHIFT + 0 Shift + 0		
+10 DISPLAY RCVR Display	DISPLAY INFO Info		

Original	Replacement	Original	Replacement
+10 DISPLAY RCVR Display	GUIDE Guide		
SEARCH ZONE 2 ENTER RCVR Zone 2	FAV PRE-CH Pre Ch		

























































Original	Replacement	Original	Replacement
	 Power		 Subt
	 +  Shift + Power		 I<<
	 Back		 Play
	 Options		 >>I
	 Ch +		 <<
	 Ch -		 Stop
	 Up		 >>
	 Left		 Text
	 Ok		 Pause
	 Right		 Eject
	 Down		 1
	 Vol +		 2
	 Vol -		 3
	 Mute		 4
	 D. Menu		 5
	 Menu		 6
	 Format		 7









































Original	Replacement	Original	Replacement
	ON		Power
	STDBY		Shift + Power
	Disc+		Ch +
	Vol+		Vol +
	Vol-		Vol -
	Muting		Mute
	I<<		I<<
	Play		Play
	>>I		>>I
	<<		<<
	Stop		Stop
	>>		>>
	Random		Text
	Pause		Pause
	Open / Close		Eject
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	+10		Guide





Original	Replacement	Original	Replacement
 ON	 Power	 3	 3
 STDBY	 Shift + Power	 4	 4
 Vol+	 Vol +	 5	 5
 Vol-	 Vol -	 6	 6
 Muting	 Mute	 7	 7
 I<<	 I<<	 8	 8
 Play	 Play	 9	 9
 >>I	 >>I	 0	 0
 <<	 <<	 +10	 Guide
 Stop	 Stop	 Enter	 Pre Ch
 >>	 >>	 Enter	 Ok
 Rec / Random	 Text		
 Rec / Random	 Rec		
 Pause	 Pause		
 Open / Close	 Eject		
 1	 1		
 2	 2		

