



































| Original  | Replacement  |
|---|--|
|  Power     |  Power    |
|  SD        |  Smart    |
|  [ + ]     |  Info     |
|  Tv/AV     |  AV       |
|  Menu      |  Menu     |
|  Exit      |  Exit     |
|  Up        |  Up       |
|  Down      |  Down     |
|  Right     |  Right    |
|  Left      |  Left     |
|  OK       |  Ok      |
|  Red     |  Red    |
|  Green   |  Green  |
|  Yellow  |  Yellow |
|  Blue    |  Blue   |
|  Tv/Text |  Text   |
|  F.P.    |  Eject  |

| Original  | Replacement   |
|---|---|
|  Index |  List    |
|  Hold  |  Options |
|  N     |  Media   |
|  CH+   |  Ch +    |
|  CH-   |  Ch -    |
|  Vol+  |  Vol +   |
|  Vol-  |  Vol -   |
|  Mute  |  Mute    |
|  1     |  1       |
|  2     |  2       |
|  3    |  3      |
|  4   |  4     |
|  5   |  5     |
|  6   |  6     |
|  7   |  7     |
|  8   |  8     |
|  9   |  9     |





