




































































Original	Replacement	Original	Replacement
 Standby	 Power	 Up	 Up
 Mute	 Mute	 Down	 Down
 P/N	 Smart	 Right	 Right
 Open/Close	 Eject	 Left	 Left
 <<	 <<	 OK	 Ok
 >>	 >>	 Vol+	 Vol +
 Play	 Play	 Vol-	 Vol -
 Pause	 Pause	 1	 1
 Stop	 Stop	 2	 2
 I<<	 I<<	 3	 3
 >>I	 >>I	 4	 4
 Setup	 Options	 5	 5
 Source	 AV	 6	 6
 Info	 Info	 7	 7
 Return/Exit	 Back	 8	 8
 CH+	 Ch +	 9	 9
 CH-	 Ch -	 0	 0



