









































































Original	Replacement	Original	Replacement
	Power		Power
	Home		Smart
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Subtitle		Subt
	Audio		Dual
	Pop-Up Menu/Disc Menu		D. Menu
	Top Menu		Menu
	Back		Back
	:≡		Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Stop		Stop
	Play		Play
	Pause		Pause
	Eject		Eject
	I<		I<<
	<<		<<
	>>		>>
	>I		>>I
	Red		Red
	Green		Green
	Yellow		Yellow





Original	Replacement
 Blue	 Blue

Original	Replacement

