



































Original	Replacement
 Power	 Power
 Vol+	 Vol+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 Return	 Back / Return
 PR+	 CH+ / Page+
 >>	 >>  / Preset+
  <<	  << / Preset-
 PR-	 CH- / Page-
 Exit	 Exit / Cancel / Clear
 Menu	 Menu / Home
 Up	 Up
 Down	 Down
 Right/Zoom+	 Right
 Left/Zoom-	 Left
 OK	 OK
 Red	 Red / Netflix / Search






















Original	Replacement
 Sound	 Sound / Title
 Green	 Green / APP / Repeat
 List	 Shift + Smart / List
 Yellow	 Yellow / YouTube / Repeat
 Info	 Info / Angle
 Mosaic	 Smart / List
 Blue	 Blue / Prime Video / Random
 Violet	 Display / Media
 Text	 Text / Goto
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8










Original	Replacement
 Power	 Power
 Vol+	 Vol+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 Return	 Back / Return
 PR+	 CH+ / Page+
 >>	 >>  / Preset+
 PR-	 CH- / Page-
  <<	  << / Preset-
 Exit	 Exit / Cancel / Clear
 Menu	 Menu / Home
 Up	 Up
 Down	 Down
 Right/Zoom+	 Right
 Left/Zoom-	 Left
 OK	 OK
 Red	 Red / Netflix / Search


































Original	Replacement
 Sound	 Sound / Title
 Green	 Green / APP / Repeat
 List	 Shift + Smart / List
 Info	 Info / Angle
 Yellow	 Yellow / YouTube / Repeat
 Mosaic	 Smart / List
 Blue	 Blue / Prime Video / Random
 Violet	 Display / Media
 Text	 Text / Goto
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8










Original	Replacement
 Power	 Power
 Vol+	 Vol+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 Return	 Back / Return
 PR+	 CH+ / Page+
 >>	 >>  / Preset+
  <<	  << / Preset-
 PR-	 CH- / Page-
 Exit	 Exit / Cancel / Clear
 Menu	 Menu / Home
 Up	 Up
 Down	 Down
 Right/Zoom+	 Right
 Left/Zoom-	 Left
 OK	 OK
 Red	 Red / Netflix / Search

Original	Replacement
 Sound	 Sound / Title
 List	 Shift + Smart / List
 Green	 Green / APP / Repeat
 Info	 Info / Angle
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Mosaic	 Smart / List
 Violet	 Display / Media
 Text	 Text / Goto
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8





Original		Replacement		Original		Replacement	
	9		9				
	0/-/-		0				
	AV		AV / Input / RDS				
	PIP		Zoom / Size				
	<</Pat-Mix		<< / Tune-				
	Play/?		Play / Slow				
	>>		>> / Tune+				
	Rec/100		Rec / Rec Mode				
	Stop		Stop / Hold				
	Pause/----		Pause / Step / Freeze				
	Size PIP		Picture / Format				
	Position PIP		TV/Radio /				

