



Original	Replacement	Original	Replacement
	Power		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TTX/MIX		Text
	PRE-CH		Pre Ch
	Mute		Mute
	CH List		List
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -
	Settings		Options
	Home		Smart
	Guide		Guide
	Info		Info
	Rec		Rec
	Enter		Ok
	Up		Up
	Down		Down
	Left		Left
	Right		Right
	Return		Back
	Exit		Exit
	Red		Red
	Green		Green





Original	Replacement	Original	Replacement
 Yellow	 Yellow		
 Blue	 Blue		
 Play	 Play		
 Pause	 Pause		
 <</ <<	 <<		
 >>/>>	 >>		
 Stop	 Stop		
 AD/Subt.	 Subt		
 Pic Size	 Format		
 Picture	 Shift + Format		

