































|   | Original | Replacement   | Original | Replacement |
|---|----------|---|----------|-------------|
|    | Power    |  Power         |          |             |
|    | Mute     |  Mute / Dimmer |          |             |
|    | Vol+     |  Vol+          |          |             |
|    | Vol-     |  Vol-          |          |             |
|    | CH+      |  CH+ / Page+   |          |             |
|    | CH-      |  CH- / Page-   |          |             |
|    | Back     |  Back / Return |          |             |
|    | Smart    |  Smart / List  |          |             |
|    | Up       |  Up            |          |             |
|   | Down     |  Down         |          |             |
|  | Left     |  Left        |          |             |
|  | Right    |  Right       |          |             |
|  | OK       |  OK          |          |             |
|  | 3D       |  3           |          |             |
|   |          |   |          |             |
|   |          |   |          |             |
|   |          |   |          |             |


























| Original     | Replacement      |
|--------------|------------------|
| Power        | Power            |
| OK           | OK               |
| Up           | Up               |
| Down         | Down             |
| Right        | Right            |
| Left         | Left             |
| Back         | Back / Return    |
| Vol +        | Vol+             |
| Vol -        | Vol-             |
| Home / Smart | Menu / Home      |
| 3D           | +  Shift + 3     |
| Mute         | Mute / Dimmer    |
| P +          | CH+ / Page+      |
| P -          | CH- / Page-      |
| Ratio        | Picture / Format |
| List         | Smart / List     |
| Q.Menu       | D.Menu / Top     |

| Original       | Replacement                 |
|----------------|-----------------------------|
| Subtitle       | Subtitle / EQ               |
| Settings       | Setup / OPT /               |
| >>             | >>I / Preset+               |
| >>             | >> / Tune+                  |
| Play           | Play / Slow                 |
| AD / PIP       | Sound / Title               |
| <<             | I<< / Preset-               |
| <<             | << / Tune-                  |
| Rec            | Rec / Rec Mode              |
| Pause          | Pause / Step / Freeze       |
| Text           | Text / Goto                 |
| FAV            | Fav / Marker / PC           |
| Exit           | Exit / Cancel / Clear       |
| Input          | AV / Input / RDS            |
| Blue           | Blue / Prime Video / Random |
| Yellow         | Yellow / YouTube / Repeat   |
| Stop / Live TV | Stop / Hold                 |





| Original   | Replacement   |
|------------|---|
| AV Mode    |  +  Shift + AV / Input / RDS  |
| Green      |  Green / APP / Repeat  |
| Red        |  Red / Netflix / Search  |
| 0          |  0   |
| AD         |  Audio / Lang I/II   |
| TV / PC    |  +  Shift + Fav / Marker / PC |
| Search     |  +  Shift + Red / Netflix /   |
| App        |  +  Shift + Green / APP /     |
| TV / Radio |  TV/Radio /  |
| Guide      |  Guide / EPG / -/--   |
| Info       |  Info / Angle  |
| Recent     |  Sleep / Timer   |
| 9          |  9   |
| 8          |  8   |
| 7          |  7   |
| Live Menu  |  Display / Media   |
| 6          |  6   |

| Original      | Replacement   |
|---------------|---|
| 5             |  5   |
| Q.View        |  +  Shift + Display / Media     |
| 4             |  4   |
| Live Zoom     |  Zoom / Size   |
| 3             |  3   |
| 2             |  2   |
| 1             |  1   |
| T.Opt         |  +  Shift + Setup / OPT / Tools |
| Energy Saving |  Eject / Surround  |
| My APPS       |  +  Shift + Smart / List      |
|               |   |
|               |   |
|               |   |
|               |   |
|               |   |
|               |   |
|               |   |
|               |   |
|               |   |

