







































































Original	Replacement	Original	Replacement
 Power	 Power	 →□←	 3D 3D
 Mute	 MUTE Mute	 OK	 OK Ok
 1	 1	 Up	 Up
 2	 2	 P+	 + Ch +
 3	 3	 P-	 - Ch -
 4	 4	 Down	 Down
 8	 8	 Right	 Right
 5	 5	 Vol+	 + Vol +
 6	 6	 Left	 Left
 7	 7	 Vol-	 - Vol -
 9	 9	 Red	 A Red
 0	 0	 Green	 B Green
 Source	 TIMER AV AV	 Yellow	 C Yellow
 Recall	 FAV PRE-CH Pre Ch	 Blue	 D Blue
 Menu	 TOP MENU MENU Menu	 [i+]	 DISPLAY INFO Info
 Exit	 CLEAR EXIT Exit	 SWAP	 PROG SLEEP Sleep
 [<>]	 PICTURE FORMAT Format	 O I	 SOUND DUAL Dual



