









































































| Original | | Replacement | | Original | | Replacement | |
|---|----------|---|-----------------------------|---|---------|---|-----------------------|
|  | Power |  | Power |  | [≡] |  | Text / Goto |
|  | Screen |  | Picture / Format |  | 9 |  | 9 |
|  | Lang |  | Audio / Lang I/II |  | 0 |  | 0 |
|  | Subtitle |  | Subtitle / EQ |  | Recall |  | Back / Return |
|  | World |  | Smart / List |  | Up |  | Up |
|  | Red/↑ |  | Red / Netflix / Search |  | Menu |  | Menu / Home |
|  | Green/↓ |  | Green / APP / Repeat |  | Right |  | Right |
|  | Yellow |  | Yellow / YouTube / Repeat |  | Left |  | Left |
|  | Blue |  | Blue / Prime Video / Random |  | Return |  | Shift + Back / Return |
|  | 1 |  | 1 |  | Return |  | Exit / Cancel / Clear |
|  | 2 |  | 2 |  | Down |  | Down |
|  | 3 |  | 3 |  | OK |  | OK |
|  | 4 |  | 4 |  | Source |  | AV / Input / RDS |
|  | 5 |  | 5 |  | FAV |  | Fav / Marker / PC |
|  | 6 |  | 6 |  | Presets |  | Display / Media |
|  | 7 |  | 7 |  | Sleep |  | Sleep / Timer |
|  | 8 |  | 8 |  | Vol+ |  | Vol+ |





| Original | | Replacement | | Original | Replacement |
|---|------|---|--------------------|----------|-------------|
|  | PR+ |  | CH+ / Page+ | | |
|  | Info |  | Info / Angle | | |
|  | Mute |  | Mute / Dimmer | | |
|  | EPG |  | Guide / EPG / -/-- | | |
|  | Vol- |  | Vol- | | |
|  | PR- |  | CH- / Page- | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

