







































































Original	Replacement
	 Mute / Dimmer
	 Power
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 Setup / OPT /
	 0
	 AV / Input / RDS
	 Shift + 1
	 Sound / Title
	 Picture / Format

Original	Replacement
	 Info / Angle
	 Up
	 Left
	 OK
	 Right
	 Down
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Vol+
	 Text / Goto
	 Menu / Home
	 CH+ / Page+
	 Vol-
	 Back / Return
	 TV/Radio /





Original		Replacement		Original		Replacement	
	CH-		CH- / Page-				
	FAV		Fav / Marker / PC				
	Subtitle		Subtitle / EQ				
	Audio		Audio / Lang I/II				
	Guide		Guide / EPG / -/--				
	[?]		Shift + Info / Angle				
	[≡x]		Shift + 5				
	[:]≡]		Shift + 4				
	[⇕]		Shift + 3				
	[⇕]		Shift + 2				
	PIP Pos		D.Menu / Top				
	PIP Size		Zoom / Size				
	PIP		Eject / Surround				

