


































| Original  | Replacement   |
|---|---|
|  Power       |  Power                       |
|  Rec         |  Rec / Rec Mode              |
|  Red         |  Red / Netflix / Search      |
|  I<<         |  I<< / Preset-               |
|  Green/[ ]   |  Green / APP / Repeat        |
|  Stop        |  Stop / Hold                 |
|  Yellow      |  Yellow / YouTube / Repeat   |
|  Play/[≡]    |  Play / Slow                 |
|  Blue/[■]    |  Blue / Prime Video / Random |
|  >>I        |  >>I / Preset+              |
|  AV/[?]    |  AV / Input / RDS          |
|  I-II/[≡≡] |  Audio / Lang I/II         |
|  [->]/[+]  |  Picture / Format          |
|  [-S-]     |  Zoom / Size               |
|  Menu      |  Menu / Home               |
|  [≡]       |  Text / Goto               |
|  Pause     |  Pause / Step / Freeze     |

| Original  | Replacement  |
|---|--|
|  Left        |  Left           |
|  Up          |  Up             |
|  Right       |  Right          |
|  OK          |  OK             |
|  Down        |  Down           |
|  Vol+        |  Vol+           |
|  Mute        |  Mute / Dimmer  |
|  P+          |  CH+ / Page+    |
|  Vol-        |  Vol-           |
|  Smart ♪    |  Sound / Title |
|  P-        |  CH- / Page-  |
|  Smart [ ] |  Smart / List |
|  1         |  1            |
|  2         |  2            |
|  3         |  3            |
|  4         |  4            |
|  5         |  5            |











| Original |      | Replacement |                   | Original |  | Replacement |  |
|----------|------|-------------|-------------------|----------|--|-------------|--|
|          | 6    |             | 6                 |          |  |             |  |
|          | 7    |             | 7                 |          |  |             |  |
|          | 8    |             | 8                 |          |  |             |  |
|          | 9    |             | 9                 |          |  |             |  |
|          | [i+] |             | Info / Angle      |          |  |             |  |
|          | 0    |             | 0                 |          |  |             |  |
|          | P<P  |             | Fav / Marker / PC |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |





| Original  | Replacement   |
|---|---|
|  0             |  Eject / Surround          |
|  -0-           |  Subtitle / EQ             |
|  Power         |  Power                     |
|  Rec           |  Rec / Rec Mode            |
|  I<<           |  I<< / Preset-             |
|  Red           |  Red / Netflix / Search    |
|  Green/[ [ ] ] |  Green / APP / Repeat      |
|  Stop          |  Stop / Hold               |
|  Play          |  Play / Slow               |
|  Yellow / List |  Yellow / YouTube / Repeat |
|  >>I         |  >>I / Preset+            |
|  AV/[?]      |  AV / Input / RDS        |
|  I-II/[≡≡]   |  Audio / Lang I/II       |
|  [<>]/[+]    |  Zoom / Size             |
|  PIP [■]     |  Picture / Format        |
|  Menu        |  Menu / Home             |
|  Pause       |  Pause / Step / Freeze   |

| Original  | Replacement   |
|---|---|
|  [≡]         |  Text / Goto     |
|  Left        |  Left            |
|  Up          |  Up              |
|  Right       |  Right           |
|  OK          |  OK              |
|  Down        |  Down            |
|  Vol+        |  Vol+            |
|  Mute        |  Mute / Dimmer   |
|  P+          |  CH+ / Page+     |
|  Vol-        |  Vol-            |
|  Smart J   |  Sound / Title |
|  P-        |  CH- / Page-   |
|  Smart [ ] |  Smart / List  |
|  1         |  1             |
|  2         |  2             |
|  3         |  3             |
|  4         |  4             |





























| Original |      | Replacement |                   | Original |  | Replacement |  |
|----------|------|-------------|-------------------|----------|--|-------------|--|
|          | 5    |             | 5                 |          |  |             |  |
|          | 6    |             | 6                 |          |  |             |  |
|          | 7    |             | 7                 |          |  |             |  |
|          | 8    |             | 8                 |          |  |             |  |
|          | 9    |             | 9                 |          |  |             |  |
|          | [i+] |             | Info / Angle      |          |  |             |  |
|          | 0    |             | 0                 |          |  |             |  |
|          | P<P  |             | Fav / Marker / PC |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |
|          |      |             |                   |          |  |             |  |





| Original   | Replacement   |
|--|---|
|  Power      |  Power                 |
|  -O-        |  Subtitle / EQ         |
|  I<<        |  I<< / Preset-         |
|  >>I        |  >>I / Preset+         |
|  AV/[?]     |  AV / Input / RDS      |
|  I-II/[≡ ≡] |  Audio / Lang I/II     |
|  [<>]/[+]   |  Zoom / Size           |
|  Pause      |  Pause / Step / Freeze |
|  [≡]        |  Text / Goto           |
|  Left      |  Left                 |
|  Up       |  Up                  |
|  Right    |  Right               |
|  OK       |  OK                  |
|  Down     |  Down                |
|  Vol+     |  Vol+                |
|  Mute     |  Mute / Dimmer       |
|  P+       |  CH+ / Page+         |

| Original  | Replacement   |
|---|---|
|  Vol-      |  Vol-                |
|  Smart J   |  Sound / Title       |
|  P-        |  CH- / Page-         |
|  Smart [ ] |  Smart / List        |
|  1         |  1                   |
|  2         |  2                   |
|  3         |  3                   |
|  4         |  4                   |
|  5         |  5                   |
|  6        |  6                  |
|  7       |  7                 |
|  8       |  8                 |
|  9       |  9                 |
|  0       |  0                 |
|  P<P     |  Fav / Marker / PC |

