





































































Original		Replacement		Original		Replacement	
	Power		Power		Sleep		Sleep
	Mute		Mute		CH +		Ch +
	1		1		CH -		Ch -
	2		2		Menu		Menu
	3		3		Up		Up
	4		4		Down		Down
	5		5		Right		Right
	6		6		Left		Left
	7		7		OK		Ok
	8		8		Exit		Exit
	9		9		Mode		Media
	0		0		TV / Radio		TV/R
	Info		Info		Freeze		Pause
	Back		Back		Subtitle		Subt
	Vol +		Vol +		Text		Text
	Vol -		Vol -		P.Mode		Shift + Format
	Nicam / A2		3D		S.Mode		Dual





Original		Replacement		Original	Replacement
	Mix		Smart		
	Hold		Stop		
	Index		Shift + Info		
	Subpage		AV		
	Reveal		D. Menu		
	Red		Red		
	Green		Green		
	Size		Format		
	Yellow		Yellow		
	Blue		Blue		
	Zoom		Eject		
	Fav-CH		Pre Ch		
	EPG		Guide		
	CH List		List		

