























































Original	Replacement	Original	Replacement
 Power	 Power	 OK	 Ok
 Mute	 Mute	 Down	 Down
 1	 1	 Left	 Left
 2	 2	 Right	 Right
 3	 3	 Menu	 Menu
 4	 4	 Return	 Back
 5	 5	 Tv/Radio	 TV/R
 6	 6	 O)/A-B	 Dual
 7	 7	 List	 List
 8	 8		
 9	 9		
 0	 0		
 Vol+	 Vol +		
 Vol-	 Vol -		
 Prog+	 Ch +		
 Prog-	 Ch -		
 Up	 Up		

