







































































| Original | Replacement | Original | Replacement |
|---|--------------|---|------------------------------|
|  | Power |  | Power |
|  | Mute |  | Mute / Dimmer |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | Goto |  | Text / Goto |
|  | Info |  | Info / Angle |
|  | Slow |  | Shift + Play / |
|  | Zoom |  | Zoom / Size |
|  | Repeat |  | Shift + Green / APP / Repeat |
|  | A - B |  | Yellow / YouTube / Repeat |
|  | << |  | << / Tune- |
|  | Play / Pause |  | Play / Slow |
|  | Play / Pause |  | Pause / Step / Freeze |
|  | >> |  | >> / Tune+ |
|  | I<< |  | I<< / Preset- |
|  | Stop |  | Stop / Hold |
|  | >>I |  | >>I / Preset+ |
|  | Menu |  | Menu / Home |
|  | Vol - |  | Vol- |
|  | Vol + |  | Vol+ |
|  | Exit |  | Exit / Cancel / Clear |
|  | Up |  | Up |
|  | Left |  | Left |
|  | OK |  | OK |
|  | Right |  | Right |
|  | Down |  | Down |





| Original | Replacement | Original | Replacement |
|----------|--------------|----------|-----------------------------|
| | Option | + | Shift + Setup / OPT / Tools |
| | Setup | | Setup / OPT / |
| | TV SYS | | D.Menu / Top |
| | Audio | | Audio / Lang I/II |
| | Subtitle | | Subtitle / EQ |
| | 16:9 / 4:3 | | Picture / Format |
| | Red | | Red / Netflix / Search |
| | Green | | Green / APP / Repeat |
| | Open / Close | | Eject / Surround |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

