





















































Original	Replacement	
On/Off		Power
Next		>>I
Audio Out		Mute
Slow Down	 + 	Shift + <<
F.Adv	 + 	Shift + Media
Mon/TV		Subt
Sp/Lp/Speed		Eject
Stop		Stop
Slow/Dpss-	 + 	Shift + Ch -
Auto/Track		Smart
Video/Go-To		D. Menu
Slow/Dpss+	 + 	Shift + Ch +
Pause		Pause
Menu		Menu
VCR/TV		Media
Menu Up		Up
Display		Info

Original	Replacement	
Menu Left		Left
OK Enter		Ok
Menu Right		Right
Exit		Exit
Menu Down		Down
T.Set/Clock		Back
Tracking+		Vol +
Tracking-		Vol -
Prev.		I<<
Audio		Dual
1		1
2		2
3		3
4		4
5		5
6		6
7		7



Original	Replacement	Original	Replacement
8	 8	Counter/Memor	 Green
9	 9	Input Source	 AV
-/--	 Guide	Counter Reset	 Yellow
0	 0	Skip/Search	 Shift + TV/R
Progr/C/CH	 Pre Ch	Info/Intro	 Shift + Info
Store	 Shift + Smart	Repeat	 Text
Rewind	 <<	Audio Dub	 Shift + Dual
Case Tape	 3D	Frame Up	 Ch +
Next Sv+V	 Shift + >>I	Timer/Record	 Shift + AV
Play	 Play	Frame Down	 Ch -
Vps/Pdc	 Format	Timer/Sleep	 Sleep
F.Forward	 >>	X2 Rew/Play	 List
Search Index	 TV/R		
Record	 Rec		
Encode	 Options		
On/Off	 Shift + Power		
Counter Clock	 Red		

Original	Replacement	Original	Replacement
Counter/Memor	 Green	Counter/Memor	 Green
Input Source	 AV	Input Source	 AV
Counter Reset	 Yellow	Counter Reset	 Yellow
Skip/Search	 Shift + TV/R	Skip/Search	 Shift + TV/R
Info/Intro	 Shift + Info	Info/Intro	 Shift + Info
Repeat	 Text	Repeat	 Text
Audio Dub	 Shift + Dual	Audio Dub	 Shift + Dual
Frame Up	 Ch +	Frame Up	 Ch +
Timer/Record	 Shift + AV	Timer/Record	 Shift + AV
Frame Down	 Ch -	Frame Down	 Ch -
Timer/Sleep	 Sleep	Timer/Sleep	 Sleep
X2 Rew/Play	 List	X2 Rew/Play	 List

