



Original	Replacement	Original	Replacement
	Power		Vol -
	1		OK
	2		Down
	3		CH / Page-
	4		Info / Angle
	5		D. Menu / Top
	6		Mute / Dimmer
	7		Text / Goto
	8		Red / Netflix / Search
	9		Rec / Rec Mode
	0		Green / APP / Repeat
	AV		Sleep / Timer
	Up		Yellow / YouTube / Repeat
	P+		Picture / Format
	Right		Blue / Private Video / Random
	Vol +		Sound / Title
	Left		Shift + CH / Page-



