Mandis shop

PackardBell STUDIO

Original	Replacement
Power	Power
Mute	Mute
Home	Smart
Home	Menu
Up	Up
Left	Left
Play / Enter	Ok
Play / Enter	Play
Right	Right
Down	Down
Vol +	Vol +
Vol -	Vol -
Info	Info
Back	Back
Setup	Options
List	List
Repeat	Text

Original	Replacement
Angle	Format
Subtitle	Subt
Audio/EQ	Dual
TV / Radio	TV/R
Zoom	Eject
Pause	Pause
Stop	Stop
Rotate	AV
I<<	I<<
<<	<<
>>	>>
>>I	>>I