































































































Original	Replacement	Original	Replacement
 Power	 Power	 Stop	 Stop
 Source	 AV	 <<	 <<
 1	 1	 Play	 Play
 2	 2	 Pause	 Pause
 3	 3	 >>	 >>
 4	 4	 Mute	 Mute
 5	 5	 Vol+	 Vol +
 6	 6	 Vol-	 Vol -
 7	 7	 P-	 Ch -
 8	 8	 P+	 Ch +
 9	 9	 Menu	 Menu
 0	 0	 Exit	 Exit
 -/--	 Guide	 Up	 Up
 PRE-CH	 Pre Ch	 Down	 Down
 TV	 TV/R	 Right	 Right
 CH.MGR	 Smart	 Left	 Left
 Wiselink	 Media	 Enter	 Ok



































































Original	Replacement
 [= ?]/Info	 Info
 [= +]/PIP	 3D
 TTX/MIX	 Text
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 I-II/Dual	 Dual
 (O)/SRS	 Back
 Source (Green)	 Shift + AV
 PC	 List
 [▼]/STTL	 Subt
 [<>]/Size	 Format
 [= ♦]/P.Mode	 Shift + Format
 [=]/S.Mode	 Options
 Sleep	 Sleep
 Power Cable	 Shift + Power

Original	Replacement
 1 Cable	 Shift + 1
 2 Cable	 Shift + 2
 3 Cable	 Shift + 3
 4 Cable	 Shift + 4
 5 Cable	 Shift + 5
 6 Cable	 Shift + 6
 7 Cable	 Shift + 7
 8 Cable	 Shift + 8
 9 Cable	 Shift + 9
 0 Cable	 Shift + 0
 P+ Cable	 Shift + Ch +
 P- Cable	 Shift + Ch -





Original	Replacement	Original	Replacement
 Power	 Power	 Stop	 Stop
 1	 1	 Play	 Play
 2	 2	 Pause	 Pause
 3	 3	 >>	 >>
 4	 4	 Menu	 Menu
 5	 5	 Exit	 Exit
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 Enter	 Ok
 PRE-CH	 Pre Ch	 [≡?]/Info	 Info
 TV	 TV/R	 [<>]/Size	 Format
 Sleep	 Sleep	 Source	 AV
 P+	 Ch +		
 P-	 Ch -		
 <<	 <<		





Original	Replacement	Original	Replacement
Power	Power	P+	Ch +
1	1	P-	Ch -
2	2	Up	Up
3	3	Enter	Ok
4	4	Down	Down
5	5	Right	Right
6	6	Left	Left
7	7	Menu	Menu
8	8	Exit	Exit
9	9	[≡?]/Info	Info
0	0		
TV	TV/R		
<<	<<		
Stop	Stop		
Play	Play		
Pause	Pause		
>>	>>		

