













































	Original	Replacement		Original	Replacement
	On/Stand-by	 Power		I<<	 I<<
	MUTE	 Mute		>>I	 >>I
	CINEMA (SOUND)	 Red		VOL+	 Vol +
	MUSIC (SOUND)	 Green		VOL -	 Vol -
	NEWS (SOUND)	 Yellow			
	BYPASS (SOUND)	 Blue			
	SURROUND	 Dual			
	INPUT	 AV			
	VOL+(TV)	 Shift + Vol +			
	VOL-(TV)	 Shift + Vol -			
	POWER (TV)	 Shift + Power			
	SOURCE TV	 Shift + AV			
	CH+(TV)	 Ch +			
	CH-(TV)	 Ch -			
	PAIRING	 Smart			
	PLAY	 Play			
	PAUSE	 Pause			



(BLUETOOTH)