







































































| Original | Replacement | Original | Replacement |
|--|---|---|--|
|  Power |  Power |  TV |  TV/R |
|  Info |  Info |  1 |  1 |
|  Audio |  Dual |  2 |  2 |
|  Mix |  Shift + Text |  3 |  3 |
|  Mute |  Mute |  4 |  4 |
|  Menu / Exit |  Menu |  5 |  5 |
|  Menu / Exit |  Exit |  6 |  6 |
|  Up / CH+ |  Up |  7 |  7 |
|  Up / CH+ |  Ch + |  8 |  8 |
|  Down / CH- |  Down |  9 |  9 |
|  Down / CH- |  Ch - |  0 / Recall |  0 |
|  Left / Vol- |  Left |  Time |  AV |
|  Left / Vol- |  Vol - |  Play |  Play |
|  Right / Vol+ |  Right |  Red / DPA/List |  Red |
|  Right / Vol+ |  Vol + |  Red / DPA/List |  List |
|  OK |  Ok |  Green / Store |  Green |
|  Text |  Text |  Yellow / Delete |  Yellow |



