




Original	Replacement	Original	Replacement
 Power	 Power	 Prog+	 Ch +
 1	 1	 Prog-	 Ch -
 2	 2	 Menu	 Menu
 3	 3	 List	 List
 4	 4	 Back	 Back
 5	 5	 Exit	 Exit
 6	 6	 Up	 Up
 7	 7	 Left	 Left
 8	 8	 OK	 Ok
 9	 9	 Right	 Right
 0	 0	 Down	 Down
 EPG	 Guide	 Red	 Red
 Info	 Info	 Green	 Green
 Vol+	 Vol +	 Yellow	 Yellow
 Vol-	 Vol -	 Blue	 Blue
 Smart	 Smart	 Audio	 Dual
 Mute	 Mute	 Sub	 Subt

Original	Replacement	Original	Replacement
 Prog+	 Ch +	 Prog-	 Ch -
 Menu	 Menu	 List	 List
 Back	 Back	 Exit	 Exit
 Up	 Up	 Left	 Left
 OK	 Ok	 Right	 Right
 Down	 Down	 Red	 Red
 Red	 Red	 Green	 Green
 Green	 Green	 Yellow	 Yellow
 Yellow	 Yellow	Blue	Blue
Blue	Blue	Audio	Dual
Audio	Dual	Sub	Subt





Original	Replacement	Original	Replacement
 Text	 Text		
 2View	 TV/R		
 APP	 Media		
 Play / Pause	 Play		
 Play / Pause	 Pause		
 Stop	 Stop		
 Rec	 Rec		
 I<< PREV	 I<<		
 >>I NEXT	 >>I		
 << REW	 <<		
 >> FWD	 >>		

