





































































































Original	Replacement	Original	Replacement
 Power	 Power	 ♪ / S.Mode	 Shift + Dual
 [i+]	 Info	 ⏻ / P.Mode	 Shift + Format
 DTT/TV	 TV/R	 Vol+	 Vol +
 AV1	 Shift + 1	 Vol-	 Vol -
 AV2	 Shift + 2	 I/II	 Dual
 AV3	 Shift + 3	 Mute	 Mute
 AV4	 Shift + 4	 P+	 Ch +
 AV5	 Shift + 5	 P-	 Ch -
 RGB1	 Shift + 7	 1	 1
 RGB2	 Shift + 8	 2	 2
 Menu	 Menu	 3	 3
 Back	 Back	 4	 4
 Up	 Up	 5	 5
 Down	 Down	 6	 6
 Right	 Right	 7	 7
 Left	 Left	 8	 8
 OK	 Ok	 9	 9

































Original		Replacement		Original		Replacement	
	0		0				
	2-4-12 / [ ]< >		3D				
	[ ]≡		Options				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	[ ]≡i		List				
	[ ]≡X		Smart				
	[ ]≡/Slide Show		Subt				
	[ ]≡?/Rotate		Pre Ch				
	[ ]≡		Text				
	Swivel		Sleep				
	[ ]<>		Format				
	Photo		Media				













































	Original	Replacement	Original	Replacement
	Power			
	OK			
	Up			
	Down			
	Right			
	Left			
	Menu			
	Play			
	Stop			
	Pause			
	<<			
	>>			
	P+			
	P-			





Original		Replacement		Original		Replacement	
	Power		Power		8		8
	OK		Ok		9		9
	Up		Up		0		0
	Down		Down				
	Right		Right				
	Left		Left				
	P+		Ch +				
	P-		Ch -				
	Vol+		Vol +				
	Vol-		Vol -				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				

