



Original	Replacement
Power	Power
Mute	Mute / Dimmer
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
-/-	Shift + Guide / EPG / -/-
Recall	Back / Return
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat

Original	Replacement
Blue	Blue / Prime Video / Random
Source	AV / Input / RDS
Vol+	Vol+
Vol-	Vol-
CH+	CH+ / Page+
CH-	CH- / Page-
Audio	Audio / Lang I/II
Aspect	Eject / Surround
Display	Display / Media
Tv/Radio	TV/Radio /
Rec	Rec / Rec Mode
Up	Up
Left	Left
OK/CH List	OK
Right	Right
Down	Down
Menu	Menu / Home



