



	Original	Replacement
	Power	 Power
	3D	 3D / Invert
	Source	 Source
	Ratio	 Blank / Mute
	Mode	 Mode
	Up	 Up
	Down	 Down
	Right	 Right
	Left	 Left
	Enter/Play/Pause	 Enter
	Stop/Back	 Shift + Power
	Menu	 Menu
	1/Freeze	 Freeze / Timer
	2/VGA	 Auto
	3/HDMI/MHL	 Volt / Focus
	4/PgUp	 Vol + / Page +
	5/Component	 Shift + Comp / Video

	Original	Replacement
	6/Video	 Comp / Video
	7/PgDn	 Vol - / Page -
	8/Media	 Eco / Aspect
	9/LAN/WIFI	 Help / Info
	0/Hide	 Shift + 3D /
	Zoom In	 + / Play
	Zoom Out	 - / Stop

