



| Original | | Replacement | | Original | | Replacement | |
|-------------------------------------------------------------------------------------|-------|-------------------------------------------------------------------------------------|-------------------|---------------------------------------------------------------------------------------|--------------|---------------------------------------------------------------------------------------|-----------------------------|
|  | Power |  | Power |  | CH+ |  | CH+ / Page+ |
|  | Mute |  | Mute / Dimmer |  | CH- |  | CH- / Page- |
|  | 1 |  | 1 |  | ≡ |  | D.Menu / Top |
|  | 2 |  | 2 |  | Input |  | AV / Input / RDS |
|  | 3 |  | 3 |  | Smart Colors |  | Display / Media |
|  | 4 |  | 4 |  | Up |  | Up |
|  | 5 |  | 5 |  | Down |  | Down |
|  | 6 |  | 6 |  | Right |  | Right |
|  | 7 |  | 7 |  | Left |  | Left |
|  | 8 |  | 8 |  | OK |  | OK |
|  | 9 |  | 9 |  | Back |  | Back / Return |
|  | 0 |  | 0 |  | Exit |  | Exit / Cancel / Clear |
|  | EPG |  | Guide / EPG / -/- |  | Red |  | Red / Netflix / Search |
|  | Rec |  | Rec / Rec Mode |  | Home |  | Menu / Home |
|  | Info |  | Info / Angle |  | Green |  | Green / APP / Repeat |
|  | Vol+ |  | Vol+ |  | Yellow |  | Yellow / YouTube / Repeat |
|  | Vol- |  | Vol- |  | Blue |  | Blue / Prime Video / Random |



