







| Original   | Replacement   |
|--|---|
|  Power          |  Power                   |
|  Open/Close     |  Text / Goto             |
|  1              |  1                       |
|  2              |  2                       |
|  3              |  3                       |
|  4              |  4                       |
|  5              |  5                       |
|  6              |  6                       |
|  7              |  7                       |
|  8              |  8                       |
|  9             |  9                      |
|  0            |  0                     |
|  Clear        |  Exit / Cancel / Clear |
|  Enter        |  Fav / Marker / PC     |
|  Time/Text    |  Setup / OPT /         |
|  Picture Mode |  Sleep / Timer         |
|  Audio        |  Audio / Lang I/II     |

| Original   | Replacement   |
|--|---|
|  Subtitle       |  Subtitle / EQ               |
|  Angle          |  Red / Netflix / Search      |
|  Sur            |  Eject / Surround            |
|  Search Mode    |  AV / Input / RDS            |
|  Repeat         |  Shift + Setup / OPT / Tools |
|  A-B            |  Shift + Play /              |
|  Shuffle        |  Yellow / YouTube / Repeat   |
|  SA-CD          |  Smart / List                |
|  Album+         |  CH+ / Page+                 |
|  Album-         |  CH- / Page-                 |
|  Zoom          |  Shift + Text /             |
|  Picture Navi |  Zoom / Size               |
|  >>           |  >>  / Preset+             |
|   <<          |  << / Tune-                |
|  >> /  >      |   << / Preset-             |
|  << / <       |  >> / Tune+                |
|  ← / <        |  Shift + << /              |








Tune-









| Original  | Replacement  | Original | Replacement |
|---|--|----------|-------------|
|  Power   |  Power              |          |             |
|  1       |  1                  |          |             |
|  2       |  2                  |          |             |
|  3       |  3                  |          |             |
|  4       |  4                  |          |             |
|  5       |  5                  |          |             |
|  6       |  6                  |          |             |
|  7       |  7                  |          |             |
|  8       |  8                  |          |             |
|  9      |  9                 |          |             |
|  0     |  0                |          |             |
|  Enter |  OK               |          |             |
|  Input |  AV / Input / RDS |          |             |
|  Vol+  |  Vol+             |          |             |
|  Vol-  |  Vol-             |          |             |
|   |  |          |             |
|   |  |          |             |

