








| Original | Replacement | Original | Replacement |
|---|--------------|---|--------------------|
|  | Power |  | Power |
|  | Open / Close |  | Eject / Surround |
|  | Language |  | Audio / Lang I/II |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | Angle |  | Info / Angle |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | Subtitle |  | Subtitle / EQ |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | Prog |  | TV/Radio / |
|  | 0/10 |  | 0 |
|  | 10+ |  | Guide / EPG / -/-- |
|  | Time |  | Sleep / Timer |
|  | << Rev |  | << / Tune- |
|  | >> Fwd |  | >> / Tune+ |
|  | I<< Prev |  | I<< / Preset- |
|  | >>I Next |  | >>I / Preset+ |
|  | Menu |  | Menu / Home |
|  | Up |  | Up |
|  | Title |  | Sound / Title |
|  | Left |  | Left |
|  | Enter |  | OK |
|  | Right |  | Right |
|  | Setup |  | Setup / OPT / |
|  | Down |  | Down |
|  | PBC |  | Picture / Format |
|  | Vol - |  | Vol- |
|  | Vol + |  | Vol+ |
|  | Zoom |  | Zoom / Size |



