



































































































Original	Replacement	Original	Replacement
 Ouvrir/Fermer	 Eject / Surround	 8	 8
 Video/Y	 AV / Input / RDS	 9	 9
 Marche	 Power	 Sous Titre	 Subtitle / EQ
 Menu	 Menu / Home	 Annul	 Exit / Cancel / Clear
 Mode	 Smart / List	 0	 0
 Affichage	 Display / Media	 10+	 Guide / EPG / -/-
 NTSC/PAL	 Picture / Format	 Config	 Setup / OPT /
 Chercher	 Red / Netflix / Search	 Retour	 Back / Return
 1	 1	 Up	 Up
 2	 2	 Left	 Left
 3	 3	 Valider	 OK
 Angle	 Info / Angle	 Right	 Right
 4	 4	 Arrêter	 Stop / Hold
 5	 5	 Down	 Down
 6	 6	 Zoom	 Zoom / Size
 Titre	 Sound / Title	 Pause	 Pause / Step / Freeze
 7	 7	 Lecture	 Play / Slow





Original	Replacement
 Volume-	 Vol-
 Volume+	 Vol+
 <I Ralenti	 CH- / Page-
 Ralenti I>	 CH+ / Page+
 I<< Chapitre	 I<< / Preset-
 Chapitre >>I	 >>I / Preset+
 Ret.Rap	 << / Tune-
 AV.Rap	 >> / Tune+
 Rpt A-B	 Yellow / YouTube / Repeat
 Repeter	 Green / APP / Repeat
 Audio	 Audio / Lang I/II
 Langue	 Shift + Audio / Lang I/II
 3D	 Shift + 3
 Silence	 Mute / Dimmer

Original	Replacement

