



| Original | Replacement |
|----------|-----------------------|
| | Menu / Home |
| | Picture / Format |
| | Green / APP / Repeat |
| | Play / Slow |
| | Pause / Step / Freeze |
| | Smart / List |
| | I<< / Preset- |
| | CH- / Page- |
| | CH+ / Page+ |
| | >>I / Preset+ |
| | Subtitle / EQ |
| | Vol- |
| | Vol+ |
| | 0 |
| | Display / Media |
| | Fav / Marker / PC |
| | 1 |

| Original | Replacement |
|----------|-------------|
| | 2 |
| | 3 |
| | 4 |
| | 5 |
| | 6 |
| | 7 |
| | 8 |
| | 9 |

