



Original	Replacement
	Power
	AV / Input / RDS
	Display / Media
	Eject / Surround
	Mute / Dimmer
	Vol-
	Vol+
	Menu / Home
	Up
	Info / Angle
	Left
	Stop / Hold
	OK
	Right
	Down
	Picture / Format
	Sound / Title

Original	Replacement
	Setup / OPT /
	Zoom / Size
	Shift + Picture / Format
	D.Menu / Top
	Fav / Marker / PC
	Back / Return
	Sleep / Timer

