








































Original	Replacement
 Pause	 Pause / Step / Freeze
 Play	 Play / Slow
 CH-	 CH- / Page-
 CH+	 CH+ / Page+
 EQ	 Subtitle / EQ
 Vol-	 Vol-
 Vol+	 Vol+
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 0	 0
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7

Original	Replacement
 8	 8
 9	 9

