



































































Original		Replacement		Original		Replacement	
	Standby		Power		7		7
	Open / Close		Eject		8		8
	Angle		Format		9		9
	Display / Info		Info		0		0
	Q-Play / TV/Radio		TV/R		Random		Smart
	Q-Play / TV/Radio		Shift + Play		Audio		Dual
	P/N / EPG		Guide		Vol+		Vol +
	Search / TTX		Text		Vol-		Vol -
	Search / TTX		Shift + TV/R		Stop		Stop
	PBC / List		List		Play		Play
	Subtitle		Subt		Pause		Pause
	1		1		Red / Prev		Red
	2		2		Red / Prev		I<<
	3		3		Green / Next		Green
	4		4		Green / Next		>>I
	5		5		Yellow / REW		Yellow
	6		6		Yellow / REW		<<





Original		Replacement		Original		Replacement	
	Blue / FF		Blue		Rec / Repeat	 + 	Shift + Text
	Blue / FF		>>		A-B / FAV		Pre Ch
	Setup		Options		Exit / Slow		Exit
	Return		Back		Video	 + 	Shift + AV
	Up / CH+		Up		Exit / Slow	 + 	Shift + >>
	Up / CH+		Ch +		Step	 + 	Shift + Pause
	Down / CH-		Down		DVD / DVB		AV
	Down / CH-		Ch -		Mute		Mute
	Right		Right				
	Left		Left				
	Enter		Ok				
	Title / Pg Up	 + 	Shift + Ch +				
	Title / Pg Up		Media				
	Menu / Pg Dn		Menu				
	Menu / Pg Dn	 + 	Shift + Ch -				
	Zoom / PVR	 + 	Shift + Eject				
	Rec / Repeat		Rec				

