






















































	Original	Replacement		Original	Replacement
	Standby		Power		Source
	Mute		Mute / Dimmer		Menu
	Play / Size		Play / Slow		Up
	Pause /		Pause / Step / Freeze		Left
	Stop / Hold		Stop / Hold		OK
	<<		<< / Tune-		Right
	>>		>> / Tune+		Exit
	<<		<< / Preset-		Down
	>>		>> / Preset+		Recall
	S.Mode		Sound / Title		Vol+
	Audio		Audio / Lang I/II		CH. List
	Subtitle		Subtitle / EQ		CH+ / Page+
	Pic. Mode		Picture / Format		Vol-
	Sleep		Sleep / Timer		Display
	TV / Radio		TV/Radio /		CH- / Page-
	Index		D.Menu / Top		1
	Text		Text / Goto		2





Original	Replacement
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
FAV	Fav / Marker / PC
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Aspect	Shift + Picture / Format
Home	Shift + Menu /
Reveal	Shift + Back / Return
Mouse	Shift + Smart / List

Original	Replacement
IE	Shift + Display / Media

