































































Original		Replacement		Original		Replacement	
	Power		Power		0		0
	Picture		Shift + Format		FAV		Pre Ch
	Sound		Shift + Dual		Recall		Back
	Input		AV		CH+		Ch +
	Menu		Menu		CH-		Ch -
	Exit		Exit		Vol+		Vol +
	16:9/4:3		Format		Vol-		Vol -
	Info		Info		Mute		Mute
	1		1		Up		Up
	2		2		Down		Down
	3		3		Right		Right
	4		4		Left		Left
	5		5		OK		Ok
	6		6		Subtitle		Subt
	7		7		Audio		Dual
	8		8		Goto		Guide
	9		9		Repeat		Shift + Text



