



Original	Replacement
Power	Power
1	1
2	2
3	3
Red	Red / Netflix / Search
4	4
5	5
6	6
Green	Green / APP / Repeat
7	7
8	8
9	9
Yellow	Yellow / YouTube / Repeat
Recall	Back / Return
0	0
Display	Display / Media
Blue	Blue / Prime Video / Random

Original	Replacement
P.Mode	Picture / Format
Text	Text / Goto
CH+	CH+ / Page+
CH+	Up
Vol-	Vol-
Vol-	Left
Menu	Menu / Home
Vol+	Vol+
Vol+	Right
CH-	Down
CH-	CH- / Page-
S.Mode	Sound / Title
Mute	Mute / Dimmer
Zoom / Sub	Zoom / Size
Still	Pause / Step / Freeze
Lang	Audio / Lang I/II
Video / Index	Info / Angle





Original	Replacement	Original	Replacement
S-Video / Hold	Stop / Hold		
PC / Size	Fav / Marker / PC		
Source / Reveal	AV / Input / RDS		
YPbPr / Cancel	Exit / Cancel / Clear		
Swap / Mix	Smart / List		

Original	Replacement

