



Original	Replacement
Power	Power
Repeat	Text
A-B	+ Shift + Text
Open / Close	Eject
N / P	TV/R
Subtitle	Subt
Angle	Format
Language	Dual
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9

Original	Replacement
0	0
10+	Guide
Time	AV
Setup	Options
Title	Media
Up	Up
Right	Right
Down	Down
Left	Left
Enter	Ok
PBC	Smart
Menu	Menu
Vol -	Vol -
Vol +	Vol +
Zoom	+ Shift + Eject
Return	Back
L / R	+ Shift + Dual





Original	Replacement
Step	Shift + Pause
Slow	Shift + Play
Clear	Exit
Program	Sleep
Mute	Mute
Display	Info
Prev <<	<<
Next >>	>>
Rev <<	<<
Fwd >>	>>
Stop	Stop
Play / Pause	Play
Play / Pause	Pause
V-Mode	3D

Original	Replacement

