







































































Original		Replacement		Original		Replacement	
	Power		Power		Slow		AV
	Mute		Mute		Menu		Menu
	1		1		EPG		Guide
	2		2		Exit		Exit
	3		3		Zoom		Smart
	4		4		Navi		Media
	5		5		Play		Play
	6		6		Pause		Pause
	7		7		<<		<<
	8		8		>>		>>
	9		9		Rec		Rec
	0		0		Stop		Stop
	Info		Info		UP		Up
	ADV		Pre Ch		Down		Down
	Page+		>>		Right		Right
	Page-		<<		Left		Left
	Audio		Dual		OK		Ok





Original		Replacement		Original		Replacement	
	CH+		Ch +				
	CH-		Ch -				
	Vol+		Vol +				
	Vol-		Vol -				
	TV/Radio		TV/R				
	Teletext		Text				
	Subtitle		Subt				
	Return		Back				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				

