



Original	Replacement
Power	Power
TV	Smart / List
Text	Text / Goto
Source 2	Shift + AV / Input / RDS
Source 1	AV / Input / RDS
1	1
2	2
3	3
Contrast-	I<< / Preset-
Contrast+	>>I / Preset+
4	4
5	5
6	6
Brightness-	Down
Brightness+	Up
7	7
8	8

Original	Replacement
9	9
Sol-	<< / Tune-
Sol+	>> / Tune+
=<	Shift + CH- /
0	0
-/ / =>	Shift + CH+ /
-/ / =>	Guide / EPG / -/ -
Fa-	Left
Fa+	Right
Vol-	Vol-
Vol+	Vol+
><-	CH- / Page-
><+	CH+ / Page+
OO	Sound / Title
I-II	Audio / Lang I/II
[]	Zoom / Size
Mute	Mute / Dimmer



