


























































Original	Replacement	Original	Replacement
	Power		Power
	FAV		Pre Ch
	TV / RAD		TV/R
	SUB		Subt
	Mute		Mute
	Up / Channel +		Up
	Up / Channel +		Ch +
	Down / Channel -		Down
	Down / Channel -		Ch -
	Right / Vol +		Right
	Right / Vol +		Vol +
	Left / Vol -		Left
	Left / Vol -		Vol -
	OK / Play		Ok
	OK / Play		Play
	Text		Text
	Sat / Stop		Media
	Sat / Stop		Stop
	Back		Back
	Menu		Menu
	i / Rec		Info
	i / Rec		Rec
	EPG		Guide
	Page + / >>		>>
	Page - / <<		<<
	AV		AV
	Audio		Dual
	Pause		Pause
	Red / Contrast -		Red
	Green / Contrast		Green
	Yellow / Brightness -		Yellow
	Blue / Brightness		Blue
	1		1
	2		2





	Original	Replacement		Original	Replacement
	3		3		
	4		4		
	5		5		
	6		6		
	7		7		
	8		8		
	9		9		
	0		0		

