





































Original	Replacement
 Power	 Power
 SAT	 AV
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Texts	 Smart
 Back	 Back
 Vol +	 Vol +
 Vol -	 Vol -

Original	Replacement
 Menu	 Menu
 Exit	 Exit
 Guide	 Guide
 CH +	 Ch +
 CH -	 Ch -
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Page Down	 Shift + Ch -
 Page Up	 Shift + Ch +
 Info	 Info
 Subtitle	 Subt
 Audio	 Dual
 Check	 Shift + Ok
 Red	 Red





Original	Replacement
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Res	 Format
 Sleep	 Sleep
 TV / Radio	 TV/R
 Text	 Text
 Play	 Play
 Stop	 Stop
 Pause	 Pause
 Rec	 Rec
 Repeat	 Shift + Text
 Step	 Shift + Pause
 <<	 <<
 >>	 >>
 Picture	 Shift + Format
 Play Text	 Shift + Play

Original	Replacement
 I<<	 I<<
 >>I	 >>I
 List	 List
 Zoom	 Eject
 Mark	 Pre Ch

