






























































Original		Replacement		Original		Replacement	
	Index		Play / Slow		6		6
	Red / -1		Red / Netflix / Search		Contrast-		<< / Tune-
	Green / Timer /		Green / APP / Repeat		Contrast+		>> / Tune+
	Yellow / Stop		Yellow / YouTube / Repeat		7		7
	Blue / Reveal		Blue / Prime Video / Random		8		8
	[≡]]]		Rec / Rec Mode		9		9
	Cancel		Exit / Cancel / Clear		Brightness-		I<< / Preset-
	Size		Zoom / Size		Brightness+		>>I / Preset+
	TV		TV/Radio /		P/C		Back / Return
	Text		Text / Goto		0		0
	1		1		AV		AV / Input / RDS
	2		2		←•→		Display / Media
	3		3		**		Smart / List
	Tint-		Shift + Left		PIP		Picture / Format
	Tint+		Shift + Right		i		Info / Angle
	4		4		i		Menu / Home
	5		5		----		Subtitle / EQ





Original	Replacement	Original	Replacement
 -1	 Red / Netflix / Search	 *+	 >> / Preset+
 / +1	 Green / APP / Repeat	 P/C	 Back / Return
 STOP	 Yellow / YouTube / Repeat	 0	 0
 E7	 Blue / Prime Video / Random	 PIP	 Picture / Format
	 Text / Goto	 i	 Info / Angle
	 1	 P+	 CH+ / Page+
	 2	 Up	 Up
	 3		 Mute / Dimmer
	 4	 Left	 Left
	 5	 Vol-	 Vol-
	 6	 OK	 OK
	 << / Tune-	 Right	 Right
	 >> / Tune+	 Vol+	 Vol+
	 7	 AUX	 Shift + 7
	 8	 P-	 CH- / Page-
	 9	 Down	 Down
	 << / Preset-		 Power

