







































































Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	↔		Pre Ch
	Back		Back
	Menu		Menu
	Netflix		Media
	Internet		Smart
	Ok		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	Mute		Mute
	i		Info
	Exit		Exit
	Source		AV
	Q.Menu		D. Menu
	EPG		Guide
	TXT		Text
	*		Format
	*/Q		3D





Original	Replacement	Original	Replacement
[>]	Options		
Lang	Dual		
Subt.	Subt		
[+]	+ Shift + Format		
TV	TV/R		
Red	Red		
Green	Green		
Yellow	Yellow		
Blue	Blue		
Rec	Rec		
Play	Play		
Stop	Stop		
Pause	Pause		
<<	<<		
>>	>>		

