



































































































Original	Replacement	Original	Replacement
	Power		Power
	Source		AV
	TV/DTV		Smart
	TV/Radio		TV/R
	Zoom		Eject
	Mute		Mute
	Media		Media
	Rec		Rec
	Sleep		Sleep
	I/II		Dual
	Lang		Options
	Subtitle		Subt
	FAV-	 + 	Shift + Ch -
	FAV		Pre Ch
	FAV+	 + 	Shift + Ch +
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Menu		Menu
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Info		Info
	EPG		Guide
	CH+		Ch +
	CH-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Picture		Format
	Sound	 + 	Shift + Dual





Original		Replacement		Original		Replacement	
	1		1		>>/Index		>>
	2		2		Stop/Size		Stop
	3		3		I<</Reveal		I<<
	4		4		>>I/Subpage		>>I
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	Still		3D				
	Text		Text				
	Recall		Back				
	PVR List		List				
	Play/T-Shift		Play				
	Pause		Pause				
	<</Hold		<<				

