





































































Original	Replacement	Original	Replacement
 Power	 Power	 <<	 <<
 Eject	 Eject	 Play	 Play
 Tv/VCR	 TV/R	 >>	 >>
 AV	 AV	 Pause/Still	 Pause
 CM Skip	 Smart	 Stop	 Stop
 1	 1	 LP	 Format
 2	 2	 i	 Info
 3	 3	 OK/CLK/CNT	 Ok
 4	 4	 Rec/OTR	 Rec
 5	 5	 Clear	 Exit
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 C.Lock	 Blue
 ez Power Off	 Media		
 ez Repeat	 Text		

Original	Replacement	Original	Replacement
 MUTE	 MUTE	 TV	 AUX
 DVD	 SAT	 PLAY MODE	 REC MODE
 SOUND	 AD	 DISC NAV	 SETTINGS
 PICTURE	 ECO	 LIST	 OPT
 E-MANUAL	 TIMER	 PROG	 3D
 D.MENU	 AV	 SLEEP	 TV/R
 TOP MENU	 DISPLAY INFO	 REPEAT	 ZOOM
 MENU	 INFO	 D.MENU	 TEXT
 CLEAR	 RETURN BACK	 REPEAT	 ZOOM
 EXIT	 BACK	 E-MANUAL	 TIMER
 VOL +	 HOME SMART	 D.MENU	 TEXT
 VOL -	 APP MEDIA	 REPEAT	 ZOOM
 1	 CH +	 D.MENU	 TEXT
 2	 CH -	D.MENU	TEXT
3	GUIDE	D.MENU	TEXT
4	FAV	D.MENU	TEXT
5	PRE-CH	D.MENU	TEXT
6	A	D.MENU	TEXT
7	B	D.MENU	TEXT
8	C	D.MENU	TEXT
9	D	D.MENU	TEXT
0	Mandis SHOP	D.MENU	TEXT
GUIDE	www.mandis.tv	D.MENU	TEXT

