



















































































| Original   | Replacement   | Original  | Replacement  |
|--|---|---|--|
|  Power  |  Power             |  Recall    |  Pre Ch   |
|  TV/SAT |  AV                |  Exit      |  Exit     |
|  Mute   |  Mute              |  OK        |  Ok       |
|  1      |  1                 |  Up        |  Up       |
|  2      |  2                 |  Down      |  Down     |
|  3      |  3                 |  Right     |  Right    |
|  4      |  4                 |  Left      |  Left     |
|  5      |  5                 |  Vol+      |  Vol +    |
|  6      |  6                 |  Vol-      |  Vol -    |
|  7      |  7                 |  CH/Page+  |  Ch +     |
|  8     |  8                |  CH/Page- |  Ch -    |
|  9    |  9               |  Red     |  Red    |
|  0    |  0               |  TTX     |  Text   |
|  SAT  |  Smart           |  Green   |  Green  |
|  FAV  |  Shift + Pre Ch |  SUB. T  |  Subt   |
|  Menu |  Menu            |  SUB. T  |  Subt   |
|  EPG  |  Guide           |  Yellow  |  Yellow |
|  |   |  Zoom    |  Eject  |

| Original  | Replacement  | Original   | Replacement  |
|---|--|--|--|
|  Recall    |  Pre Ch   |  TV         |  AUX      |
|  Exit      |  Exit     |  DVD        |  SAT      |
|  OK        |  Ok       |  MUTE       |  SHIFT    |
|  Up        |  Up       |  PLAY MODE  |  REC MODE |
|  Down      |  Down     |  TV         |  DUAL     |
|  Right     |  Right    |  SOUND      |  AD       |
|  Left      |  Left     |  DISC NAV   |  SETTINGS |
|  Vol+      |  Vol +    |  LIST       |  SUBT     |
|  Vol-      |  Vol -    |  PROG       |  OPT      |
|  CH/Page+  |  Ch +     |  SEARCH     |  PICTURE  |
|  CH/Page- |  Ch -    |  SLEEP     |  ECO     |
|  Red     |  Red    |  TV/R     |  FORMAT |
|  TTX     |  Text   |  E-MANUAL |  3D     |
|  Green   |  Green  |  REPEAT   |  TIMER  |
|  SUB. T  |  Subt   |  D.MENU   |  TEXT   |
|  SUB. T  |  Subt   |  TOP MENU |  AV     |
|  Yellow  |  Yellow |  MENU     |  INFO   |
|  Zoom    |  Eject  |  OK       |  BACK   |



