



	Original	Replacement		Original	Replacement
	Power		Power		8
	Mute		Mute		9
	ATV/DTV		Smart		0
	NR.		Play		Shift + Guide
	Still		Pause		Recall
	Aspect		Format		Volume+
	Sleep		Sleep		Volume-
	Nicam/A2		Dual		Channel+
	Surround		List		Channel-
	Bass		Options		Source
	1		1		Picture
	2		2		Sound
	3		3		Info
	4		4		ATV Menu
	5		5		DVB Menu
	6		6		Exit
	7		7		TTX
					Shift + Format
					Shift + Dual
					Info
					Menu
					D. Menu
					Exit
					Text



