



Original	Replacement	Original	Replacement
	Power		Power
	F		Setup / OPT /
	Sound Effect		Sound / Title
	Vol +		Vol+
	Mute		D.Menu / Top
	Mute		Mute / Dimmer
	Vol -		Vol-
	Equalizer		Audio / Lang I/II
	I<<		I<< / Preset-
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	>>I		>>I / Preset+
	DRC		Menu / Home
	Repeat		Green / APP / Repeat
	Auto Vol		Display / Media
	Av Sync		AV / Input / RDS
	Sleep		Sleep / Timer
	Auto Power		Exit / Cancel / Clear

