
































































Original	Replacement
 Power	 Power
 Mute	 Mute
 TV	 TV/R
 Audio	 Shift + TV/R
 Clock /Pop-Up M.	 Smart
 ->[]<- / Zoom	 Eject
 Sound	 Dual
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0 / AV	 0

Original	Replacement
 EPG	 Guide
 Media	 Media
 Pip/[]	 3D
 Text / Disc M	 Text
 Text / Disc M	 D. Menu
 Menu	 Menu
 End	 Back
 Info	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 P+	 Ch +
 P-	 Ch -



























































Original	Replacement	Original	Replacement
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue/Marker	 Blue		
 <<<	 <<<		
 Play	 Play		
 >>>	 >>>		
 Rec	 Rec		
 Pause	 Pause		
 Stop	 Stop		













Original	Replacement
 Power	 Power
 Pop-Up-M	 Smart
 →[]← / Zoom	 Eject
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/AV	 0
 EPG	 Guide
 Media	 Media
 PIP/[]	 3D
 Text / Disc-M	 Text

Original	Replacement
 Text / Disc-M	 D. Menu
 Menu	 Menu
 End	 Exit
 Info	 Info
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 P+	 Ch +
 P-	 Ch -
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue/Marker	 Blue
 <<	 <<
 Play	 Play































































Original		Replacement		Original		Replacement	
	>>		>>				
	Rec		Rec				
	Pause		Pause				
	Stop		Stop				













Original	Replacement
 Power	 Power
 Pop-Up-M	 Smart
 →[]←/Zoom	 Format
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/AV	 0
 EPG	 Guide
 Media	 Media
 PIP/[]	 3D
 Text / Disc-M	 Text

Original	Replacement
 Text / Disc-M	 D. Menu
 Menu	 Menu
 End	 Exit
 Info	 Info
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 P+	 Ch +
 P-	 Ch -
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue/Marker	 Blue
 <<	 <<
 Play	 Play







































Original		Replacement		Original		Replacement	
	>>		>>				
	Rec		Rec				
	Pause		Pause				
	Stop		Stop				

























Original	Replacement
 Power	 Power
 Mute	 Mute
 TV	 TV/R
 Audio	 Shift + TV/R
 Pop-Up M	 Smart
 Zoom	 Eject
 Sound	 Dual
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0 / AV	 0

Original	Replacement
 EPG	 Guide
 PIP/[]	 3D
 Media	 Media
 Text / Disc M	 Text
 Text / Disc M	 D. Menu
 Menu	 Menu
 End	 Back
 Info	 Info
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Vol+	 Vol +
 Vol-	 Vol -
 P+	 Ch +
 P-	 Ch -





Original		Replacement		Original		Replacement	
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue/Marker		Blue				
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	Rec		Rec				
	<<		<<				
	>>		>>				

