












| Original | Replacement | Original | Replacement |
|--|--|--|--|
|  Power |  Power |  CH+ |  Ch + |
|  Red |  Red |  CH- |  Ch - |
|  Green |  Green |  Up |  Up |
|  Yellow |  Yellow |  Down |  Down |
|  Blue |  Blue |  Right |  Right |
|  Tv/Radio |  TV/R |  Left |  Left |
|  Zoom |  Eject |  OK |  Ok |
|  List |  List |  Vol+ |  Vol + |
|  Help |  Media |  Vol- |  Vol - |
|  Audio |  Dual |  P+ |  >>I |
|  EPG |  Guide |  P- |  >> |
|  Timer |  AV |  Recall |  Back |
|  Text |  Text |  FAV |  Pre Ch |
|  Exit |  Exit |  1 |  1 |
|  Menu |  Menu |  2 |  2 |
|  MP |  Format |  3 |  3 |
|  Mute |  Mute |  4 |  4 |





| Original | Replacement | Original | Replacement |
|---|-------------|---|-------------|
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | Info |  | Info |
|  | Pause |  | Pause |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

