







































































Original		Replacement		Original		Replacement	
	Power		Power		6		6
	Open/Close		Eject / Surround		7		7
	V.Mode		Picture / Format		8		8
	OSD		Display / Media		9		9
	P/N		AV / Input / RDS		0		0
	Program		TV/Radio /		10+		Guide / EPG / -/--
	Menu		Menu / Home		Up		Up
	Title		Sound / Title		Down		Down
	Subtitle		Subtitle / EQ		Right		Right
	Angle		Info / Angle		Left		Left
	Search		Red / Netflix / Search		Enter		OK
	Setup		Setup / OPT /		PBC		Text / Goto
	1		1		Return		Back / Return
	2		2		Zoom		Zoom / Size
	3		3		Play		Play / Slow
	4		4		Pause		Pause / Step / Freeze
	5		5		Stop		Stop / Hold





	Original	Replacement	Original	Replacement
		<< / Tune-		
		>> / Tune+		
		I<< / Preset-		
		>>I / Preset+		
		Audio / Lang I/II		
		R/L D.Menu / Top		
		Shift + Slow / Play /		
		Rec / Rec Mode		
		Exit / Cancel / Clear		
		Shift + Pause / Step /		
		Yellow / YouTube / Repeat		
		Smart / List		
		Green / APP / Repeat		
		Mute / Dimmer		
		Vol+		
		Vol-		

